GIANTMACH UTV500/UTV700 WINDSHIELD ASSEMBLY INSTRUCTIONS



4 chrough 7

13









- 1. Place rubber guard around windshield fasteners.
- 2. Insert rubber garments into holes on windshield. (no figure shown)
- 3. Place metal inserts inside of rubber garments.
- 4. Starting on lower part of the UTV roll bar place windshield fastener around roll bar with the flat side facing out. (fasteners should be on the interior side of the UTV)
- 5. Hold windshield in place to where the holes on the windshield match up with those on the windshield fasteners. (windshield should be placed on top of the fasteners)
- 6. Squeeze the fastener together and insert the screw from the outside of the windshield through both the windshield and fastener.
- 7. Tighten a nut onto the screw snugly. (Do not tighten all the way as this will make it difficult to adjust windshield after all fasteners are on)
- 8. Repeat steps 4 through 7 for the 3 other lower holes on the windshield.
- 9. Place a fastener around the roll bar to where it matches up with a upper side hole on the windshield.
- 10. While squeezing the fastener, place the support bar on the inner most side of the fastener and insert a screw through the windshield, fastener, and support bar.
- 11. Tighten a nut onto the screw snugly. (Do not tighten all the way as this will make it difficult to adjust windshield after all fasteners are on)
- 12. Repeat steps 9 through 11 for the other upper side hole on windshield.
- 13. For the two upper interior holes on the windshield place a screw through the windshield and support bar; tighten with a nut snugly.
- 14. Adjust windshield if needed then tighten all fasteners.



